

CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.

The use of steam or water-based cleaners may cause excessive shrinking or staining.







NOTICE

* Please make sure that you have all parts indicated before you begin assembly of this item

* This item should be assembled on a soft surface to prevent scratching the finish during assembly

* This item may require periodic tightening


Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Seat		1X
B	Leg		2X
H1	Flat washer		8X
H2	Spring washer		8X
H3	Allen bolt		8X
H4	Allen key		1X



Model# AMH4022A

Product Dimensions: 47.25"X17"X31.25"H




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen key



Step

Assemble the legs onto the seat and screw it with washers, bolts and tighten them with Allen key
Place the seat (A) with the leg (B) and use the allen key(H4) to tighten washers and bolts