### **CARE AND MAINTENANCE**

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.

### NOTICE

- \* Please make sure that you have all parts indicated before you begin assembly of this item
- \* This item should be assembled on a soft surface to prevent scratching the finish during assembly
- \* This item may require periodic tightening

## **Part List and Hardware List**

PIECE	DESCRIPTION	PICTURE	QUANTITY
А	LEG		1X
В	LEG		1X
С	CROSS		1X
D	BAR		1X
E	TABLE TOP		1X
F	SCREW	<b>D</b>	2X
G	ALLEN BOLT	(Incommon (I)	2X(20mm)
Н	ALLEN BOLT	CONTRACTO (I)	8x(15mm)
I	ALLEN KEY		1X
J	PHILLIPS SCREW DRIVER		1X



Model# AMH6513A

Product Dimensions: 40"Wx21"Dx18"H




### **PREPARATION**

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key and Phillips Screw Driver



## Step 1

Put the Table Top (E) upside down on the ground, attach the Legs to the Top, use Allen key to tighten the Bolts (H)

## Step 2

Attach the Bar (D) to the top, use Phillips Screw Driver to tighten the screws (F), then connect the Bar with Legs, use Allen Key to tighten the Bolts(G)

# Step 3

Attach the Corss (C) to Legs, use Allen Key to tighten the Bolts (H)