




CARE AND MAINTENANCE

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening


Part List and Hardware List

PIECE	DESCRIPTION	DESCRIPTION	QUANTITY
A	TOP		1X
B	LEG		2X
C	SHELF		1X
D	ALLEN BOLT & WASHER		12X (35mm)
E	ALLEN KEY		1X

SAFAVIEH FURNITURE

Model# AMH 6604

Product Dimensions : 20"W X 16"D X 25"H




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 5 minutes.

Tools Required for Assembly (included): Allen Key



ATTN HAL
PARTS DEPT.
1991 Northampton Street
Easton, PA 18042
(610) 250-6492

Turn the Top (A) upside down, attach the legs to top, use Allen Key to tighten the bolts(D). Then attach the Shelf (C) to legs, tighten the bolts (D)