#### **CARE AND MAINTENANCE**

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.

The use of steam or water-based cleaners may cause excessive shrinking or staining.

### **NOTICE**

- \* Please make sure that you have all parts indicated before you begin assembly of this item.
- \* This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- \* This item may require periodic tightening.

# Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
А	TOP PANEL		1X
В	LEFT PANEL		1X
С	RIGHT PANEL		1X
D	FRAME		2X
E	BOTTOM PANEL		1X
F	SIDE BACK PANEL	<i>[]</i>	2X
G	CENTER BACK PANEL	<i>[]</i>	1X
Н	LEG	<b>—</b>	4X
I	UPPER DRAWER FRONT		1X
J	DRAWER LEFT		3X
K	DRAWER RIGHT		3X
L	DRAWER BACK		3X
М	DRAWER BASE		3X
N	DRAWER SUPPORT	_	3X
0	LOWER DRAWER FRONT		2X



Model# CHS5000A

Product Dimensions: 36"W x 18"D x 36"H



WEIGHT CAPACITY: TOP: 110 LBS DRAWER: 30 LBS


WARNING: DO NOT OVER TORQUE BOLTS/SCREWS

PIECE	DESCRIPTION	PICTURE	QUANTITY
1	BOLT	M6x65mm	8X
2	SPRING WASHER	0	8X
3	FLAT WASHER	0	8X
4	1 1/4" FLAT HEAD SCREW	M3x32mm <b>)</b>	33X
5	3/4" FLAT HEAD SCREW	M3x19mm <b>)</b>	18X
6	1/2" FLAT HEAD SCREW	M3x13mm <b>)</b>	12X
7	CAMBOLT	€	34X
8	CAMLOCK	3	34X
9	HANDLE	$\Diamond$	6X
10	WOODEN DOWEL		8X
11	ALLEN KEY		1X

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 60 minutes.



Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 60 minutes.



Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 60 minutes.



Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 60 minutes.



Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 60 minutes.



Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 60 minutes.



Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 60 minutes.

