WARNING

* Switch off the main electrical supply from the main fuse box / circuit breaker before installation.
* Inspect item carefully before attempting to install.
* If there is any damages or obvious defects, do not install.
* Item may not be returned once it has been installed.




CARE AND MAINTENANCE

* To clean the outside of the fixture, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the surface of the fixture.
* To clean the inside of the fixture, first disconnect power to the fixture by turning off the circuit breaker or by removing the fuse at the fuse box. Next, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the interior surface of the fixture.
* Do not use any cleaners with chemical, solvents or harsh abrasives. Use only a dry soft cloth to dust or wipe carefully.

NOTICE& IMPORTANT SAFETY INSTRUCTIONS


** WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN **
* Please make sure that you have all parts indicated before you begin assembly of this item
* This item should be assembled on a soft surface to prevent scratching the finish during assembly
* To reduce the risk of fire, electrical shock or injury to persons or property, please follow the guideline below for safe use and installation
*The external flexible cable or cord of this lamp cannot be replaced
If the cord is damaged, the lamp shall be destroyed




Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY	PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Hex nut		3X	F	Mounting bracket		1X
B	Metal washer		1X	G	Plain washer		2X
C	Threaded rod		1X	H	Outlet box screw		2X
D	Teeth washer		1X	I	Swivel joint		1X
E	Wire Nut		3X	J	Loop Ring		1X

SAFAVIEH COUTURE


Model#: CTL1013
Product Dimensions: 50"Lx23.75"Wx31.5- 61.5"H




PIECE	DESCRIPTION	PICTURE	QUANTITY	PIECE	DESCRIPTION	PICTURE	QUANTITY
K	Steel cable buckle		1X	P	12"rod		2X
L	Steel cable buckle		1X	Q	Fixture body		1X
M	Cluster		1X				
N	Canopy		1X	R	Acrylic bars		16X
O	6"rod		2X				

PREPARATION

* Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
* If any part is missing or damaged, do not attempt to assemble the product.
* Estimated Assembly Time: 20 minutes.
* Tools Required for Assembly (not included): Screwdriver, Junction box
* If you are having difficulty, our friendly Customer Care team is always here to help. Please email **customersupport@safavieh.com**




Step 1: Fasten acrylic arm(R) to fixture body(Q).




Step 2: Pass wire and cable through 6"rod (O),12"rod (P),Loop Ring(J),Swivel joint (I), Canopy(N),Mounting bracket(F) and out from side hole of Cluster (M). Then fasten 6"rod (O),12"rod (P),Swivel joint (I).

PREPARATION

* Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
* If any part is missing or damaged, do not attempt to assemble the product.
* Estimated Assembly Time: 20 minutes.
* Tools Required for Assembly (not included): Screwdriver, Junction box
* If you are having difficulty, our friendly Customer Care team is always here to help. Please email **customersupport@safavieh.com**



Step 3: Raise the threaded rod (C) thread to the cluster (M), then attach to the ceiling, secure with metal washer (B) and hex nut (A). Wrap the steel wire rope around the beam and lock it with the steel cable buckle(K) and (L).Tighten Mounting bracket(F) to Cluster (M),then fix Swivel joint (I) to Mounting bracket(F).Insert lead wire to quick-connect terminal,black to black, white to white by forcing apart the handle of quick-connect terminal(N1) to insert the wires and then loose, ensure the wires be inserted properly.



Step 4: Wire connection

Connect fixture neutral wire (ribbed) to the outlet box neutral wire (usually white) using a wire nut.

Connect fixture hot wire (smooth with markings) to the outlet box hot wire (usually black) using a wire nut.


CAUTION: Do not reverse the hot and neutral connections

Grounding Instructions:


Wrap ground wire from outlet box around green ground screw on mounting bracket, no less than 2" from wire end. Tighten ground screw. If fixture is supplied with a ground wire, connect to outlet ground wire with a wire nut.

PREPARATION

* Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
* If any part is missing or damaged, do not attempt to assemble the product.
* Estimated Assembly Time: 20 minutes.
* Tools Required for Assembly (not included): Screwdriver, Junction box
* If you are having difficulty, our friendly Customer Care team is always here to help. Please email **customersupport@safavieh.com**



Step 5: Install the mounting bracket (F) to the junction box with plain washer (G) and outlet box screw (H).



Step 6: Attach the canopy (N) to the ceiling with Loop ring (J).

Dimmable drive can be compatible with the following 10 commonly used dimmers in the United States:

Lutron DVCL-153P	Lutron MACL-153MLH-WH
Lutron P-PKG1W-WH-R	Lutron STCL-153PH-WH
Leviton R11-DSL06-1TW	Leviton R00-RNL06-0TW
Leviton R02-DW6HD-2RW	Leviton R68-06674-POT
Legrand RHCL453PNICCV4	TP-link HS220