

PREPARE AND MAINTENANCE

Do not clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning. The use of steam or water-based cleaners may cause excessive shrinking or staining.










NOTICE


Please make sure that you have all parts indicated before you begin assembly of this item.

This item should be assembled on a soft surface to prevent scratching the finish during assembly.

This item may require periodic tightening.


Part List and Hardware List

	PART NAME	QUANTITY	DESCRIPTION	QUANTITY
A	SEAT	1		1X
B	Front leg-1	1		1X
C	Front leg-2	1		1X
D	Back leg-1	1		1X
E	Back leg-2	1		1X
H1	Allen bolt L	8		8X
H2	Spring washer	8		8X
H3	Flat washer	8		8X
H4	Allen key	1		1X

 SAFAVIEH
FURNITURE

Model# MCR4712

Product Dimensions: 22.05" W x 25.79" D x 37.00" H



REPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.
Tools Required for Assembly (included): Allen Key

