

CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.
The use of steam or water-based cleaners may cause excessive shrinking or staining.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- * This item may require periodic tightening.


Parts List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Seat		1X
B	Front leg-1		1X
C	Front leg-2		1X
D	Back leg-1		1X
E	Back leg-2		1X
H1	Allen bolt		8X
H2	Spring washer		8X
H3	Flat washer		8X
H4	Allen key		1X



Model# MCR4734

Product Dimensions: 34.25" W x 33.86" D x 46.85" H



Weight Capacity: 275 lbs

WARNING: DO NOT STAND ON CHAIR

WARNING: DO NOT OVER TORQUE BOLTS/SCREWS



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 20 minutes.
Tools Required for Assembly (included): Allen Key.

The diagram consists of six numbered steps:

- Step 1:** Shows the seat (A) with hardware H1 (Allen bolt), H2 (Spring washer), H3 (Flat washer), and H4 (Allen key) being inserted into the base.
- Step 2:** Shows the seat (A) with the text "Legs inside here" and an arrow pointing to the leg attachment points.
- Step 3:** Shows the seat (A) with front legs B and C being attached. Hardware H1, H2, H3, and H4 are used to secure the legs.
- Step 4:** Shows the seat (A) with back legs D and E being attached. Hardware H1, H2, H3, and H4 are used to secure the legs.
- Step 5:** Shows the seat (A) with all four legs attached, forming the chair's frame.
- Step 6:** Shows the fully assembled chair.