



PREPARATION

Before beginning the assembly of the product, make sure all parts are present. Compare the parts with the package contents list and hardware contents list. If any parts are missing or damaged, do not attempt to assemble the product. Tool required for assembly (included): Allen Key.



Step 1: attach the back (A) and the seat (B) to the left side (C) by using the Allen Bolt (E1) and the Allen screw (E2) as shown on the picture . Then tighten it with the Allen Key (E4).



Step 2: attach the right side (D) to the seat (B) and the back (A) as shown on the picture. Then fit with the Allen Bolt (E1) and Allen Screw (E2) by using the Allen Key (E4).









CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when it is not in use. Dust regularly with small brush or vacuum. Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

NOTICE

Please make sure that you have all parts indicated before you begin assembly of this item.

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Back		1X
B	Seat		1X
C	Left side		1X
D	Right side		1X
E1	Allen Bolt	 M6x90	8X
E2	Allen Screw	 M6x90	2X
E3	Extra Bolt	 M6x50	1X
E4	Allen Key		1X

 **SAFAVIEH**
OUTDOOR LIVING

MODEL# PAT6724

Product Dimension: 38.98"W x 71.65"D x 29.13"H

Weight capacity : 600 lbs.

Warning : Do not stand on the bench

Warning : Do not torque bolts / screws

