















CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when it is not in use. Dust regularly with small brush or vacuum. Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

NOTICE

Please make sure that you have all parts indicated before you begin assembly of this item.

Part List and Hardware List

PIECE	PICTURE	DESCRIPTION	QUANTITY
1		Front legs	6X
2		Rear legs	6X
3		Table legs	4X
4		Table glass	1X
5		Table frame	1X
6		Pillow for chair	2X
7		Cushion seat for chair	2X
8		Pillow for bench	2X
9		Cushion seat for bench	2X
10		Bench frame	1X
11		Chair frame	2X
a		Bolts Ø6x25mm	32X
b		Flat Washers Ø16x1.0mm	32X
c		Allen key	2X

SAFAVIEH OUTDOOR LIVING

MODEL# PAT6758

Product dimension:

Bench: 51.8W x 26.4D x 27.6H (Inches)


Chair: 25.2W x 26.4D x 27.6H (Inches)

Table: 41W x 21D x 14.5H (Inches)

Weight Capacity: 704 lbs per bench & 55 lbs per table


Warning: do not stand on chair / bench & table

Warning: do not over torque bolts/screws




PREPARATION


Before beginning the assembly of the product, make sure all parts are present. Compare the parts with the package contents list and hardware contents list. If any parts are missing or damaged, do not attempt to assemble the product. Tool required for assembly (included): Allen Key.



Step1: Attach wood leg (1 & 2) to front and back of the chair respectively, using a & b. Loosen the bolt to balance the chair first




Step 2: Fully tighten using Key (c)




PREPARATION


Before beginning the assembly of the product, make sure all parts are present. Compare the parts with the package contents list and hardware contents list. If any parts are missing or damaged, do not attempt to assemble the product. Tool required for assembly (included): Allen Key.




Step 1: Attach wood leg (1 & 2) to front and back of the bench respectively, using a & b. Loosen the bolt to balance the bench first




Step 2: Fully tighten using Key (c)






Step 1: Attach wood leg (3) to frame, using a & b. Loosen the bolt to balance the table first



Step 2: Fully tighten using Key (c) after that put the glass on top table



Step 3: Put all cushions on the chairs and bench