#### **CARE AND MAINTENANCE**


Store outdoor furniture indoors or cover well when not in use.

Remove wooden furniture from standing water. Dust regularly with small brush or vacuum Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

# SAFAVIEH OUTDOOR

#### **NOTICE**

- \* Please make sure that you have all parts indicated before you begin assembly of this item
- \* This item should be assembled on a soft surface to prevent scratching the finish during assembly
- \* This item may require periodic tightening



Warning: Do not over torque bolts / screws









Product Dimensions:14.96" W x 18.89" D x 31.1" H




Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key

1



2



Step 1

To close:

Pull the Seat up and fold Iron Leg Frame as indicated by the arrows, by hand, until the Chair folds shut.

Note: There is a iron latch under the Seat Frame, pull this up by hand to lock/unlock the iron dowel into positon.

# Step 2

To open:

Pull the Seat forward with one hand and steady the Chair with your other hand. Unfold Leg Frame as indicated by the arrows, until the Chair folds out and locks into position. Note: There is a iron latch under the Seat Frame, pull this up by hand to lock/unlock the iron dowel into position.

#### **CARE AND MAINTENANCE**

Store outdoor furniture indoors or cover well when not in use.

Remove wooden furniture from standing water. Dust regularly with small brush or vacuum Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.



#### **NOTICE**

- \* Please make sure that you have all parts indicated before you begin assembly of this item
- \* This item should be assembled on a soft surface to prevent scratching the finish during assembly
- \* This item may require periodic tightening

#### Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Leg front and table panel		1X
В	Leg back panel		1X
С	Side panel		2X
D	Connection leg		4X
Е	Bottom panel		1X
F	Screw	<b>⊚</b> Ø6 x 50	16X
G	Allen key	LG 4	1X

Weight Capacity: 40 Ibs

Warning: Do not stand on table

Warning: Do not over torque bolts / screws








Model# PAT 7046

Product Dimensions: 25.1" W x 24.8" D x 30.31" H




Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key

1



2



Step 1
Attached Leg back panel(B) with side Panel(C) and Connection leg(D),
Using Screw(F), Tighten screw(F) with allen key (G).


Step 2

Attached Leg front panel (A) with side Panel(C) and Connection leg(D), Using Screw(F), Tighten screw(F) with allen key (G).

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key



Step 3

Using Screw(F), Tighten screw(F) with allen key (G).

Step 4


(E)Pull down as the arrow

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key





# Step 5

Pull out the legs and put them in clocks.