

CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when not in use.

Remove wooden furniture from standing water. Dust regularly with small brush or vacuum

Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

 **SAFAVIEH**
O U T D O O R











Weight Capacity : 40 lbs

Warning : Do not stand on table

Warning : Do not over torque bolts / screws




Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Bottom leg		2X
B	Leg frame		2X
C	Frame box flowers		5X
C1	Frame box flowers		1X
D	Bottom panel		3X
E	Table		1X
F	Screw -1	 M6X30	28X
G	Screw -1	 M6X50	2X
H	Bolt	 M6X25	1X
K	Allen key	 LG 4	1X

Model# PAT7047

Product Dimensions: 29.21" W x 28.81" D x 48.62" H




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key


1



Step 1

Attach leg frame (B) to Bottom leg (A), use screws-1 (F), tighten with allen key (K).

2



Step 2

Attach Frame box flowers (C), (C1) to leg frame (B), use screws-1 (F), tighten with allen key (K).


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key


3



Step 3

(D) Pull down as the arrow

4



Step 4

Attach Table (E) to leg frame (B), use screws-1 (G), tighten allen key (K).
Tighten Bolt (H) with allen key (K) to attach frame box flowers (C1) and leg short table


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key


5



Step 3

Pull out support table and put them in locks.

6



Step 4

Barley flower shelf is ready to be used

CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when not in use.

Remove wooden furniture from standing water. Dust regularly with small brush or vacuum

Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

NOTICE


- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

 **SAFAVIEH**
O U T D O O R

Weight Capacity : 300 lbs

Warning : Do not stand on chair

Warning : Do not over torque bolts / screws



Model# PAT7047

Product Dimensions: 14.96" W x 18.89" D x 31.1" H


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key

1




Step 1

To close:

Pull the Seat up and fold Iron Leg Frame as indicated by the arrows, by hand, until the Chair folds shut.

Note: There is a iron latch under the Seat Frame, pull this up by hand to lock/unlock the iron dowel into positon.

2



Step 2

To open:

Pull the Seat forward with one hand and steady the Chair with your other hand.

Unfold Leg Frame as indicated by the arrows, until the Chair folds out and locks into position.

Note: There is a iron latch under the Seat Frame, pull this up by hand to lock/unlock the iron dowel into positon.