CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when not in use.
Remove wooden furniture from standing water. Dust regularly with small brush or vacuum Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

SAFAVIEH OUTDOOR

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Weight Capacity: 600 Ibs Warning: Do not stand on table

Warning: Do not over torque bolts / screws







Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
А	Sofa Bench I		1X
В	Leg		4X
С	Allen bolt	M6x15	16X
D	Allen key		1X

Model# PAT7049

Product Dimensions: 53,34" W x 28,34" D x 30,3" H




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key





Step 1
Attach leg (B) to Sofa bench II (A), using allen bolt (C), tighten with allen key (D)

CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when not in use.
Remove wooden furniture from standing water. Dust regularly with small brush or vacuum Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

SAFAVIEH OUTDOOR

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Weight Capacity: 600 Ibs Warning: Do not stand on table

Warning: Do not over torque bolts / screws








Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
А	Sofa Bench I		1X
В	Leg		4X
С	Allen bolt	M6x15	16X
D	Allen key		1X

Model# PAT7049

Product Dimensions: 25,78" W x 28,34" D x 30,3" H




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key

1



Step 1
Attach leg (B) to Sofa bench I (A), using allen bolt (C), tighten with allen key (D)

CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when not in use.
Remove wooden furniture from standing water. Dust regularly with small brush or vacuum Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
А	Frame on table		1X
В	Leg		4X
С	Allen bolt	M6x15	16X
D	Allen key		1X



Weight Capacity: 40 Ibs

Warning: Do not stand on table

Warning: Do not over torque bolts / screws








Model# PAT7049

Product Dimensions:23,62" W x 39,37" D x 14,76" H




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key

1



Step 1
Attach leg (B) to bar (A),
using allen bolt (C), tighten with
allen key (D)