

## NOTICE

- \* Please make sure that you have all parts indicated and they are in good condition before you begin assembly of this item. Refer to part list and hardware list below for guidance.
- \* This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- \* This item may require periodic tightening.
- \* If you are having difficulty, our friendly Customer Care team is always here to help. Please email [customersupport@safavieh.com](mailto:customersupport@safavieh.com)

## PREPARATION

- \* Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- \* If any part is missing or damaged, do not attempt to assemble the product.
- \* Estimated Assembly Time: 10 minutes.
- \* Tools Required for Assembly (included): Allen Key

## CARE AND MAINTENANCE

- \* Once the fireplace is completely cooled down, remove the chimney and fire screen.
- \* Pour the ashes from the bowl and rinse with clean water and allow to dry completely.
- \* Clean after each use.
- \* Do not use a scrub brush.
- \* If the paint chips, use only high-temperature paints and a brush to fix.
- \* If rust is showing, sand lightly and repaint the area with high-temperature paints.
- \* Dry with a soft cloth.
- \* Turn the unit upside down when not in use to prevent water from collecting.
- \* Cover the unit when not in use to prolong the life.
- \* Keep your firepit out of rain.


### Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Spark arrester cap		1x
B	Chimney		1x
C	Fire screen with handle		1x
D	Grate		1x
E	Bowl		1x
F	Stand		1x
G	Poker		1x



Item No: PIT1001A

Product Dimensions : 18.00" x 18.00" x 40.00"



### ⚠ WARNING ⚠

**WARNING:** Do not use charcoal or an artificial log.

**WARNING:** Do not use large logs. Do not overload the fire bowl beyond 6 to 8 pounds.

**WARNING:** Do not use gasoline or kerosene to start a fire.

**CAUTION:** Keep the fire at a reasonable level as large fires can damage or shorten the life of the unit.

# PREPARATION

\* Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.


\* If any part is missing or damaged, do not attempt to assemble the product.

\* Estimated Assembly Time: 10 minutes.

\* Tools Required for Assembly (included): Allen Key


\* If you are having difficulty, our friendly Customer Care team is always here to help. Please email [customersupport@safavieh.com](mailto:customersupport@safavieh.com)

## 1. Assembling the bowl, log grate and fire screen




- Place the stand (F) to the upright position on a flat surface and place the bowl (E) into the stand (F).
- Place the grate (D) into the bowl (E).
- Position the fire screen (C) onto the bowl (E) so that it is resting on the inside ledge of the bowl. Make sure all components are square and level.

## 2. Assembling the chimney and spark arrester cap



- Carefully attach the spark arrester cap (A) to the chimney (B) by pushing down into the top of chimney (B).
- Carefully place chimney (B) onto the fire screen (C).

## 3. Adding wood to an existing fire



- Use the poker (G) to lift the handle and open the door of the fire screen (C) and carefully add wood while the fire is burning.
- After adding the wood, use the poker (G) to close the door of the fire screen (C).