NOTICE

- * Please make sure that you have all parts indicated and they are in good condition before you begin assembly of this item. Refer to part list and hardware list below for guidance.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- * This item may require periodic tightening.
- * If you are having difficulty, our friendly Customer Care team is always here to help. Please email customersupport@safavieh.com

PREPARATION

- * Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- * If any part is missing or damaged, do not attempt to assemble the product.
- * Estimated Assembly Time: 10 minutes.
- * Tools Required for Assembly (included): Allen Key

CARE AND MAINTENANCE

- * Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.
- * The use of steam or water-based cleaners may cause excessive shrinking or staining.


Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
А	Seat		1X
В	Front Leg	-	2X
С	Back Leg		2X
HW1	Split Lock Washer(M8)	O	2X
HW2	Flat Washer(M8)	0	2X
HW3	Socket Screws 8*1.25*50MM	(i)	2X
HW4	Allen Key		1X

SAFAVIEH COUTURE

Model#: SFV4818

Dimensions:31.1"WX32.5"DX29.3"H





Weight Capacity: 275 lbs

Warning: Do not stand on Chair

Warning: Do not over torque bolts

PREPARATION

- * Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- * If any part is missing or damaged, do not attempt to assemble the product.
- * Estimated Assembly Time: 10 minutes.
- * Tools Required for Assembly (included): Allen Key
- * If you are having difficulty, our friendly Customer Care team is always here to help. Please email customersupport@safavieh.com

• • • • • • • • • • • • • • • • • • •	B G B	C B B
STEP1 OPEN THE CARTON, TAKE OUT THE BODY, LEGS AND HARDWARE INSIDE.		STEP3 ROTATE THE BACK LEG UNTIL TIGHTEN AS SHOWN IN THE PICTURE.
C C HW4 HW4 A		
STEP4 REPEAT THE SAME STEP FOR THE OTHER BACK LEG, AND THEN INSERT THE LEGS AND SCREW IN THE SCREWS BUT DON'T TIGHTEN COMPLETELY.	STEP5 PUT THE CHAIR UPRIGHT AND MAKE SURE ALL LEGS ARE LEVEL, THEN FIRMLY TIGHTEN BOLTS WITH ALLEN KEY WHILE THE CHAIR IS UPRIGHT AS PICTURED ABOVE(IF THE CHAIR WOBBLY, YOU CAN EASY ADJUST LEG BOTTOM PLASTIC SCREW)	