







CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.
The use of steam or water-based cleaners may cause excessive shrinking or staining.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Part List and Hardware List


PIECE	DESCRIPTION	PICTURE	QUANTITY
A	SEAT		1X
B	LEGS		4X
HW1	ALLEN KEY		1X
HW2	SOCKET SCREWS 6.4 X 1.4 X 51MM		8X
HW3	SPLIT LOCK WASHER 6.4MM		8X
HW4	FLAT WASHER 6.4MM		8X

SAFAVIEH

COOUTURE

SFV7511A / SFV7511B

DIMENSIONS: 91"L x 35"D x 28"H



WEIGHT CAPACITY: 250 LBS PER SEAT

WARNING: DO NOT STAND ON SOFA
WARNING: DO NOT OVER TORQUE
BOLTS/SCREWS

The legs and hardware are located in the carton box.





PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 15 minutes.

Tools Required for Assembly (included): Allen Key

 <p>A line drawing of a sofa labeled 'A' is shown next to a rectangular box labeled 'B'. An arrow points from the box to the sofa, and another arrow points from the sofa back to the box. To the left of the box, four individual leg pieces are shown, each with a small circular hole at its base.</p>	 <p>A detailed technical diagram of the leg assembly. It shows a leg labeled 'A' being inserted into the sofa frame labeled 'B'. Four hardware components are labeled: HW1 (a long L-shaped bracket), HW2 (a long screw), HW3 (a washer), and HW4 (a shorter screw). Arrows indicate the direction of assembly.</p>
<p>STEP1 TAKE OUT LEGS AND HARDWARE FROM THE BOX.</p>	<p>STEP2 INSERT THE LEGS, PUT THE WASHERS ON THE SOCKET SCREW IN THE ORDER SHOWN IN THE PICTURE AND TIGHTEN COMPLETELY</p>
 <p>A line drawing of the sofa frame labeled 'A' with the legs labeled 'B' attached. The legs are shown as being inserted into the frame.</p>	 <p>A line drawing showing two stylized human figures standing on either side of the sofa frame labeled 'A'. A large curved arrow above the sofa indicates that it should be turned over. The legs labeled 'B' are visible at the bottom of the frame.</p>
<p>STEP3 THIS ITEM MAY REQUIRE PERIODIC TIGHTENING</p>	<p>STEP4 TURN OVER THE SOFA AND MAKE SURE ALL LEGS ARE LEVEL</p>

The legs and hardware are located in the carton box.