












CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.  
The use of steam or water-based cleaners may cause excessive shrinking or staining.

NOTICE


- \* Please make sure that you have all parts indicated before you begin assembly of this item.
- \* This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- \* This item may require periodic tightening.

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	TOP PANEL		1X
B	LEFT ASSEMBLY		1X
C	RIGHT ASSEMBLY		1X
D	FRAME 1		3X
E	FRAME 2		2X
F	BACK PANEL		1X
G	DRAWER FRONT		2X
H	DRAWER LEFT		2X
I	DRAWER RIGHT		2X
J	DRAWER BACK		2X
K	DRAWER BASE		2X












Model# NST5004A  
Product Dimensions: 18"W x 16"D x 24"H





WEIGHT CAPACITY :  
TOP : 110 LBS  
DRAWER : 30 LBS

WARNING: DO NOT OVER TORQUE  
BOLTS/SCREWS

PIECE	DESCRIPTION	PICTURE	QUANTITY
1	1 1/4" FLAT HEAD SCREW	M3x32mm 	16X
2	3/4" FLAT HEAD SCREW	M3x19mm 	4X
3	5/8" FLAT HEAD SCREW	M3x16mm 	6X
4	CAMBOLT		20X
5	CAMLOCK		20X
6	MACHINE SCREW		2X
7	HANDLE		2X
8	WOODEN DOWEL		4X
9	WEDGE		6X



**PREPARATION**

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.  
If any part is missing or damaged, do not attempt to assemble the product.  
Estimated Assembly Time: 60 minutes.  
Tools Required for Assembly : Phillips Screwdriver

	
<p><b>STEP 1</b> ATTACH CAMBOLTS TO TOP PANEL, LEFT AND RIGHT ASSEMBLIES.</p>	<p><b>STEP 2</b> ATTACH FRAMES TO TOP PANEL USING CAMLOCKS.</p>


**PREPARATION**

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.  
If any part is missing or damaged, do not attempt to assemble the product.  
Estimated Assembly Time: 60 minutes.  
Tools Required for Assembly : Phillips Screwdriver


	
<p><b>STEP 3</b> ATTACH LEFT ASSEMBLY TO UNIT USING CAMLOCKS.</p>	<p><b>STEP 4</b> ATTACH FRAME 1 AND FRAMES 2 TO UNIT USING CAMLOCKS AND DOWELS.</p>

**PREPARATION**

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.  
If any part is missing or damaged, do not attempt to assemble the product.  
Estimated Assembly Time: 60 minutes.  
Tools Required for Assembly : Phillips Screwdriver



**STEP 5** SLIDE BACK PANEL INTO THE GROOVE OF UNIT.



**STEP 6** ATTACH RIGHT ASSEMBLY TO UNIT USING CAMLOCKS AND DOWELS.



## PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.





Estimated Assembly Time: 60 minutes.

Tools Required for Assembly : Phillips Screwdriver

 <p>The diagram shows a perspective view of a square table frame. A circular callout on the left shows a close-up of a wedge (part 9) being secured to a leg with a screw (part 3). Another circular callout at the bottom shows a circular base with arrows indicating it can be rotated and moved up and down to adjust the table's stability.</p>	 <p>The diagram shows an exploded view of a drawer assembly. It includes a drawer front (G), a drawer base (K), a drawer left side (H), a drawer right side (J), a drawer back (I), and a handle (7). Arrows indicate the assembly sequence: attaching the handle to the front, then the sides to the back, and finally sliding the base into the groove formed by the sides and back.</p>
<p><b>STEP 7</b> ATTACH WEDGES TO BACK PANEL USING 5/8" FLAT HEAD SCREWS. ADJUST THE ADJUSTER THAT HAS ALREADY BEEN ASSEMBLED TO THE LEGS TO STABILIZE YOUR UNIT.</p>	<p><b>STEP 8</b> ATTACH HANDLE TO DRAWER FRONT USING MACHINE SCREWS. ATTACH DRAWER LEFT AND RIGHT TO DRAWER BACK USING 1 1/4" FLAT HEAD SCREWS. SLIDE DRAWER BASE INTO THE GROOVE. ATTACH DRAWER FRONT TO DRAWER LEFT AND RIGHT USING 1 1/4" FLAT HEAD SCREWS.</p>

**PREPARATION**

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.  
If any part is missing or damaged, do not attempt to assemble the product.  
Estimated Assembly Time: 60 minutes.  
Tools Required for Assembly : Phillips Screwdriver

	
<p><b>STEP 9</b> LOOSEN SLIGHTLY THE SCREWS PRE-INSTALLED ON THE BACK OF THE DRAWER FRONTS.</p>	<p><b>STEP 10</b> INSERT THE DRAWER INTO THE UNIT, THEN ADJUST THE DRAWER FRONT PANEL LEFT OR RIGHT AND UP OR DOWN UNTIL THE DRAWER GAPS LOOK PROPORTIONAL.</p>
	
<p><b>STEP 11</b> PULL THE DRAWER OPEN SLOWLY AND RE-TIGHTEN THE SCREWS FROM STEP 9. MAKE SURE THE FRONT PANEL DOES NOT MOVE AND LOCK THE DRAWER FRONT PANEL INTO POSITION WITH 3/4" FLAT HEAD SCREWS.</p>	<p><b>STEP 12</b> SLIDE THE DRAWERS INTO UNIT.</p>