

















CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.
The use of steam or water-based cleaners may cause excessive shrinking or staining.

NOTICE


- * Please make sure that you have all parts indicated before you begin assembly of this item.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- * This item may require periodic tightening.

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	TOP PANEL		1X
B	LEFT PANEL		1X
C	RIGHT PANEL		1X
D	BASE ASSEMBLY		1X
E	BACK PANEL		1X
F	LEG		4X
G	DRAWER FRONT		2X
H	DRAWER LEFT		2X
I	DRAWER RIGHT		2X
J	DRAWER BACK		2X
K	DRAWER BASE		2X
1	25 MM BOLT	M6x25mm 	8X
2	1 1/4" FLAT HEAD SCREW	M3x32mm 	16X
3	3/4" FLAT HEAD SCREW	M3x19mm 	8X
4	5/8" FLAT HEAD SCREW	M3x16mm 	6X
5	CAMBOLT		12X










Model# NST5010
Product Dimensions: 18"W x 15 1/2"D x 23 1/32"H





WEIGHT CAPACITY:
TOP: 50 LBS
DRAWER: 15 LBS

WARNING: DO NOT OVER TORQUE
BOLTS/SCREWS

PIECE	DESCRIPTION	PICTURE	QUANTITY
6	CAMLOCK		12X
7	WEDGE		6X
8	DOWEL		8X
9	SPRING WASHER		8X
10	ALLEN KEY		1X
11	HANDLE		2X
12	HANDLE BOLT		2X


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver


	
<p>STEP 1 ATTACH CAMBOLT TO TOP PANEL AND BASE ASSEMBLY.</p>	<p>STEP 2 ATTACH LEFT AND RIGHT PANELS TO BASE ASSEMBLY USING CAM LOCKS AND DOWELS.</p>

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver





STEP 3 SLIDE BACK PANEL TO UNIT.



STEP 4 ATTACH TOP PANEL TO UNIT USING CAMLOCKS AND DOWELS.



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver

	
<p>STEP 5 ATTACH LEGS TO UNIT USING BOLTS AND SPRING WASHERS. TIGHTEN BOLTS USING ALLEN KEY.</p>	<p>STEP 6 ATTACH WEDGE TO LOCK BACK PANEL USING 5/8" FLAT HEAD SCREW. ADJUST THE ADJUSTER BOLT THAT HAS ALREADY ASSEMBLED TO THE LEGS TO STABILIZE YOUR UNIT</p>


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver


 <p>2X</p>	
<p>STEP 7 ATTACH HANDLE TO DRAWER FRONT USING HANDLE BOLT. ATTACH DRAWER LEFT AND RIGHT TO DRAWER BACK USING 1 1/4" FLAT HEAD SCREWS. SLIDE DRAWER BASE INTO THE GROOVE. ATTACH DRAWER FRONT TO DRAWER LEFT AND RIGHT USING 1 1/4" FLAT HEAD SCREWS.</p>	<p>STEP 8 LOOSEN SLIGHTLY THE SCREWS PRE-INSTALLED ON THE BACK OF THE DRAWER FRONTS.</p>

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver





STEP 9 INSERT THE DRAWER INTO THE UNIT, THEN ADJUST THE DRAWER FRONT PANEL LEFT OR RIGHT AND UP OR DOWN UNTIL THE DRAWER GAPS LOOK PROPORTIONAL.



STEP 10 PULL THE DRAWER OPEN SLOWLY AND RE-TIGHTEN THE SCREWS FROM STEP 8.

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 60 minutes.
Tools Required for Assembly : Phillips Screwdriver

 A line drawing showing two views of a drawer unit. The left view shows a top-down perspective of the drawer front panel being secured with a screwdriver. A circular arrow indicates the rotation of the screwdriver. A dashed line points to a screw hole, labeled with a circled '3'. The right view shows a side perspective of the drawer unit with three screws, each labeled with a circled '3', being inserted into the front panel.	 A line drawing of a cabinet with two drawers. A large black arrow points towards the front of the drawers, indicating they should be slid into the unit.
<p>STEP 11 MAKE SURE THE FRONT PANEL DOES NOT MOVE AND LOCK THE DRAWER FRONT PANEL INTO POSITION WITH 3/4" FLAT HEAD SCREWS.</p>	<p>STEP 12 SLIDE THE DRAWERS INTO UNIT.</p>